



## KTD CLM Spectrometer Task

#619 IlluminationSpectrometerWavelengthFineCalibration

#626 IlluminationSpectrometerWavelengthFinePerformance/

YANN



WK1840

# Why Task 619/626

- Task 619 is in principle the same as task 600 (EPROM ECs).
- However, ASML repeats the calibration for the following reasons:
  - Task 600 provides a calibrated ECs at room temperature.
  - ASML applications require a higher accuracy than the supplier provides.
  - Task 600 Uses the supplier calibration as a coarse calibration, task 619 Uses the calibration lamp installed in the CL module to perform a fine calibration.

# YS(1)375 Source Architecture

Task#619#626: pixel to wavelength calibration/performance





## Task #619 Pixel to Wavelength Fine Calibration

# CL Module Tasks Dependencies Wrt 619 Flow




Fig. Task 619 measurement flow




Fig. CLM Task dependencies




Fig. Task dependencies

# CLM Calibration Light Source




Fig. Spectrum of the AvaLight CAL calibration lamp

| Wavelength | Regime | Atom |
|------------|--------|------|
| 253.652    | 0      | Hg   |
| 296.728    | 0      | Hg   |
| 302.150    | 0      | Hg   |
| 313.155    | 0      | Hg   |
| 334.148    | 0      | Hg   |
| 365.015    | 0      | Hg   |
| 404.656    | 2      | Hg   |
| 407.783    | 0      | Hg   |
| 435.833    | 3      | Hg   |
| 546.074    | 3      | Hg   |
| 576.960    | 2      | Hg   |
| 579.066    | 2      | Hg   |
| 696.543    | 2      | Ar   |
| 706.722    | 1      | Ar   |
| 714.704    | 0      | Ar   |
| 727.294    | 1      | Ar   |
| 738.398    | 1      | Ar   |
| 750.387    | 0      | Ar   |
| 763.511    | 3      | Ar   |
| 772.376    | 0      | Ar   |
| 794.818    | 1      | Ar   |
| 800.616    | 0      | Ar   |
| 811.531    | 0      | Ar   |
| 826.452    | 2      | Ar   |
| 842.465    | 0      | Ar   |
| 852.144    | 1      | Ar   |
| 866.794    | 0      | Ar   |
| 912.297    | 2      | Ar   |
| 922.450    | 1      | Ar   |

Totally 15 peaks will be used!

- Emits the spectral lines of Hg and Ar.
- Three intensity regimes defined
  - 0. Will not be used
  - 1. Low intensity
  - 2. Medium intensity
  - 3. High intensity
- Life time: 7 years.

# Spectra Band Build-up for Regime 1








Fig. Calibration light source measured from M6445

Fig. Pixel range expand


- Inverse lookup on the coarse pixel-wavelength EC, find the coarse central pixel.
- Expand the range by  $N_{bw}$  pixels centered around.

# Integration Time Calibration





## Integration time calibration:

- Take spectrums from  $T_{\min}$  to  $T_{\max}$  to aim for target intensity.
- Store the optimized integration time for 1 regime.
- Repeat for regime 2 and regime 3.



Get intensities within same regime




Find 1 optimized integration time




# Spectrum Acquisition

ASML




## Spectrum acquisition:

- Acquire raw spectrums at each of the three integration times.
- Calibration source off and Repeat above acquisitions.



# Average, Dark-off, Non-linearity, Irradiance

10



1. Average the dark spectrums.
2. Subtract above dark spectrum from each light spectrum.
3. Perform non-linearity correction for each spectrum
4. Perform irradiance correction for each spectrum.
5. Take average of the resulting spectrum.

Then, we have one spectrum per integration time !

$$X_j = m - \frac{1}{2} \left( \frac{\ln(I_{j,m+1}) - \ln(I_{j,m-1})}{\ln(I_{j,m-1}) + \ln(I_{j,m+1}) - 2 \ln(I_{j,m})} \right),$$




Fig. Sub-pixel detection algorithm

- Three-point Gaussian approximation to find the real center.
- The detected sub-pixel center,  $X_j$ , should correspond to certain wavelength.
- These pixels will be recorded.

# Fine Wavelength Calibration – Full Wavelength Table

$$\lambda_i = \sum_{k=0}^4 C_k i^k = C_0 + C_1 i + C_2 i^2 + C_3 i^3 + C_4 i^4,$$




Fig. 4<sup>th</sup> order polynomial fit

- After running sub-pixel peak detection algorithm, we have 15 points (red circle) in terms of wavelength vs. pixel.
- 4<sup>th</sup> order polynomial fit, this yields:
  - Full wavelength vs pixel table.
  - Coefficients  $C_k$  with  $k = 0 \sim 4$ .

This yields an array of 2048 rows contains calibrated wavelengths!

# How To Perform Task #619

## 1. Equipment constant → Sensing → Spectrometer

|   |  |
|---|--|
| [-] <b>Spectrometer</b>   |  |
| Additional delay between spectrometer acquisitions [s]                      | 0  |
| Default Integration Time For Spectrometer                                   | 0.0025   |
| Queued spectrometer acquisition mode enabled                                | False  |
| Spectrometer Calibration Lamp burn time [min]                               | 0.00   |
| Spectrometer Calibration Lamp warm up time [s]                              | 600  |
| [-] <b>Spectrometer coarse mapping of Pixel to corresponding Wavelength</b> |  |
| Spectrometer Pixel to wavelength data file name                             | <b>SpectrometerPixelToWavelength_CLIModule_20180424_110745.csv</b> |
| [-] <b>Spectrometer corrections</b>   | <b>SpectrometerCorrections</b>                                     |
| Apply spectrometer Central Wavelength Bandwidth correction                  | True   |
| Apply spectrometer DC-offset correction                                     | True   |
| Apply spectrometer Irradiance correction                                    | False  |
| Apply spectrometer Non-linearity correction                                 | False  |
| Apply spectrometer Pixel To Wavelength correction type                      | Coarse   |
| [-] <b>Spectrometer fine mapping of Pixel to corresponding Wavelength</b>   |  |
| Spectrometer Pixel to wavelength data file name                             |  |
| [-] <b>Spectrometer Irradiance calibrated values</b>                        | <b>Spectrometer Irradiance</b>                                     |
| Spectrometer Irradiance Calibrated Integration Time                         | 0  |
| Spectrometer Irradiance data file name                                      |  |
| [-] <b>Spectrometer Non-Linearity calibrated values</b>                     | <b>0   0  </b>   |
| Spectrometer Non-linearity correction coefficients                          |  |
| Spectrometer Non-linearity high boundary                                    | 0  |
| Spectrometer Non-linearity low boundary                                     | 0  |
| [-] <b>Spectrometer wavelength range</b>                                    | <b>925   350</b>   |

Coarse: task #600 EC

Make fine

Empty (#619 EC)

# How To Perform Task #619

## 3. Edit inputs.

14

illuminationSpectrometerWavelengthFineCalibration

**Input Values**

| List of Wavelengths and corresponding Intensity Regimes | (Collection) |
|---|--------------|
| Number of acquisitions for every regime [#]             | 50           |
| Number of points around spectral lines [#]              | 10           |

**Spectrometer integration time parameters High Regime [s]**

|                                  |     |
|----------------------------------|-----|
| Max IntegrationTime Coarse [s]   | 0.2 |
| Number coarse acquisitions [#]   | 15  |
| Number fine acquisitions [#]     | 5   |
| Saturation intensity level [0-1] | 0.9 |
| Target intensity level [0-1]     | 0.9 |

**Spectrometer integration time parameters Low Regime [s]**



|                                  |     |
|----------------------------------|-----|
| Max IntegrationTime Coarse [s]   | 2   |
| Number coarse acquisitions [#]   | 15  |
| Number fine acquisitions [#]     | 5   |
| Saturation intensity level [0-1] | 0.9 |
| Target intensity level [0-1]     | 0.8 |

**Spectrometer integration time parameters Medium Regime [s]**

|                                  |     |
|----------------------------------|-----|
| Max IntegrationTime Coarse [s]   | 0.8 |
| Number coarse acquisitions [#]   | 15  |
| Number fine acquisitions [#]     | 5   |
| Saturation intensity level [0-1] | 0.9 |
| Target intensity level [0-1]     | 0.8 |

Spectrometer integration time parameters Medium Regime [s]

Reset Import... Export... Close





# EC After Running #619

|   |   |
|---|---|
| <b>Spectrometer</b>   |   |
| Additional delay between spectrometer acquisitions [s]                  | 0   |
| Default Integration Time For Spectrometer                               | 0.0025  |
| Queued spectrometer acquisition mode enabled                            | False   |
| Spectrometer Calibration Lamp burn time [min]                           | <b>34.98</b>  |
| Spectrometer Calibration Lamp warm up time [s]                          | 600   |
| <b>Spectrometer coarse mapping of Pixel to corresponding Wavelength</b> |   |
| Spectrometer Pixel to wavelength data file name                         | <b>SpectrometerPixelToWavelength_CIModule_20180424_110745.csv</b>         |
| <b>Spectrometer corrections</b>   |   |
| Apply spectrometer Central Wavelength Bandwidth correction              | True  |
| Apply spectrometer DC-offset correction                                 | True  |
| Apply spectrometer Irradiance correction                                | False   |
| Apply spectrometer Non-linearity correction                             | False   |
| Apply spectrometer Pixel To WaveLength correction type                  | <b>Fine</b>   |
| <b>Spectrometer fine mapping of Pixel to corresponding Wavelength</b>   |   |
| Spectrometer Pixel to wavelength data file name                         | <b>SpectrometerPixelToWavelengthFine_CIModuleFine_20180706_035221.csv</b> |
| <b>Spectrometer Irradiance calibrated values</b>                        |   |
| Spectrometer Irradiance Calibrated Integration Time                     | <b>0</b>  |
| Spectrometer Irradiance data file name                                  |   |
| <b>Spectrometer Non-Linearity calibrated values</b>                     |   |
| Spectrometer Non-linearity correction coefficients                      | <b>0   0  </b>  |
| Spectrometer Non-linearity high boundary                                | <b>0</b>  |
| Spectrometer Non-linearity low boundary                                 | <b>0</b>  |
| <b>Spectrometer wavelength range</b>                                    |   |
| Highest spectrometer wavelength [nm]                                    | <b>925</b>  |
| Lowest spectrometer wavelength [nm]                                     | <b>350</b>  |
| <b>Spot Size Selector</b>   |   |
| Spot size selector encoder positions                                    | <b>EncoderPositionPSpotEntry[] Array</b>                                  |
| <b>Switch Mirror Selector</b>   |   |
| Default Switch Mirror Darkfield position [m]                            | <b>0.0026104</b>  |
| Default Switch Mirror Pupil position [m]                                | <b>0.013885</b>   |
| Switch Mirror Darkfield position [m]                                    | <b>0.0026104</b>  |
| Switch Mirror Pupil position [m]  | <b>0.013885</b>   |

# How to Verify Task #619


1. Select task #626, check input setting, run the task.





# How to Verify Task #619

2. Check the following specification in #626 report:



**Mean Difference All Spectra**  
[nm]

-1.3020560618315358E-05

**Three Sigma of found peak positions**  
[pm]

55.04428864209379

< 0.05nm

3std of the performance measurement and calibration  
data < 0.05nm

The background features a light blue gradient with abstract, flowing white and light blue lines that create a sense of movement and depth. The ASML logo is positioned on the left side, and the text 'Q & A' is on the right.

**ASML**

**Q & A**