




**KTD CLM Spectrometer Tasks**  
**#604 IlluminationSpectrometerDCOffsetCalibration**  
**#623 IlluminationSpectrometerDCOffsetPerformance**

Tina


wk1840

# CLM Optical Structure



Task#604: Spectrometer DC  
Offset calibration

— Main path  
— Spectrometer path  
— Calibration path



# The DC offset origin

The dark current offset has DC and AC components:

DC

1. Electronic offset such as programmed DC offset
2. Integrated dark photodiode current.

AC


1. Dark current shot noise
2. Read-noise




Position

Integration  
time

Temperature



Dark current would increase as the temperature increases



The fitted equation

$$\hat{y}_i = b_0 + b_1 x$$

Minimize the error sum of squares (SSE)

$$SSE = \sum_{i=1}^n (y_i - \hat{y}_i)^2 = \sum_{i=1}^n (y_i - (b_0 + b_1 x))^2$$


Through some calculation, obtain the coefficients  $b_0$ ,  $b_1$ ,

$$b_1 = \frac{\sum_{i=1}^n (x_i - \bar{x})(y_i - \bar{y})}{\sum_{i=1}^n (x_i - \bar{x})^2}$$

$$b_0 = \bar{y} - b_1 \bar{x}$$

# Spectrometer DC Offset Calibration In Task #604


- Dark current offset is an offset of the spectrum in **dark** conditions.



Sensing	Time [s] to wait to ensure ShutterS-Ctrl command has been executed	0.015
Focus	Time [s] to wait to ensure WaveLength-Ctrl command has been executed	0.01
Simulation		
SoftwareLayout		
UserInterface		
WaferHandler		
	<b>Spectrometer</b>	
	Additional delay between spectrometer acquirememts [s]	0
	Default Integration Time For Spectrometer	0.0025
	Queued spectrometer acuisition mode enabled	False
	<b>Spectrometer corrections</b>	<b>SpectrometerCorrections</b>
	Apply spectrometer Central Wavelength Bandwidth correction	True
	Apply spectrometer DC-offset correction	True
	Apply spectrometer Irradiance correction	False
	Apply spectrometer Non-linearity correction	False
	<b>Spectrometer DC Offset</b>	<b>Spectrometer DC Offset</b>
	Elbow integration time [ms]	0.25
	Spectrometer DC Offset file name	SpectrometerDCOffset_DCOffset_20180327_044111.csv
	<b>Spectrometer Irradiance calibrated values</b>	<b>Spectrometer Irradiance</b>
	<b>Spectrometer mapping of Pixel to corresponding Wavelength</b>	
	<b>Spectrometer Non-Linearity calibrated values</b>	0   0
	<b>Spectrometer wavelength range</b>	925   350
	<b>Spot Homogeneity Images</b>	
	Spot Homogeneity Detection calibration images	(Collection)
	Spot Homogeneity Illumination calibration images	(Collection)
	<b>Spot Size Selector</b>	
	Spot sizeselector encoderpositions	EncoderPositionPSpotEntry[] Array
	<b>Switch Mirror Selector</b>	

# Spectrometer DC Offset Calibration In Task #604

For a specific pixel  
100 acquisitions for each integration time



1. Apply linear regression to obtain the coefficients, C and S, of the fitting line.

$$I = C + S \tau$$

2. Calculate the slope scaling factor (using the last 12 dark pixels)

$$f = \frac{\sum_{i=N-11}^N I_i - C_i}{\sum_{i=N-11}^N S_i \cdot t},$$

3. Subtract the fitted spectra from the measured spectra to get the corrected spectra I'

$$I' = I - C - f S t.$$

# How to perform task #604

## 1. Equipment constant → Sensing → Spectrometer

Measuring	Time [s] to wait to ensure WaveLength-Ctrl command has been executed	0.01
NumberCruncher	<b>Spectrometer</b>	
Positioning	Additional delay between spectrometer acuirememts [s]	0
<b>Sensing</b>	Default Integration Time For Spectrometer	0.0025
Focus	Queued spectrometer acuisition mode enabled	False
Simulation	<b>Spectrometer corrections</b>	<b>SpectrometerCorrections</b>
SoftwareLayout	Apply spectrometer Central Wavelength Bandwidth correction	True
UserInterface	Apply spectrometer DC-offset correction	False → Make True
WaferHandler	Apply spectrometer Irradiance correction	False
	Apply spectrometer Non-linearity correction	False
	<b>Spectrometer DC Offset</b>	<b>Spectrometer DC Offset</b>
	Elbow integration time [ms]	0.25
	Spectrometer DC Offset file name	SpectrometerDCOffset_DCOffset_20180327_062207.csv
	<b>Spectrometer Irradiance calibrated values</b>	<b>Spectrometer Irradiance</b>

## 2. Select task #604, check the default input setting and commit ECs if there is no problem

Tasks Batch

604

● IlluminationSpectrometerDCOffsetCalibration Sensing - Illumination

IlluminationSpectrometerDCOffsetCalibration

Integration Time Domain

min [ms]	0.03
elbow [ms]	0.25
max [ms]	2.5

Number Of Integration Time Points

Number of points [min, elbow]	12
Number of points [elbow, max]	23

Time over which to take data

Duration for calibration [s]	120
------------------------------	-----


Duration for calibration [s]

Reset Import... Export... Close

Default input setting	
Minimal integration time[ms]	0.03
Elbow integration time [ms]	0.25
Maximal integration time [ms]	2.5
Number of points [min, elbow]	12
Number of point(elbow, max]	23
Duration for calibration [s]	120

# How to verify task #604

1. Select task #623, check input setting, run the task.



Input setting of task #623	
Minimal integration time[ms]	0.03
Maximal integration time [ms]	2.5
Number of points	50
Duration for calibration [s]	10


2. Check the following specification:

</Table

Maximal Offset Level Noise ( $3\sigma$ ) [DN16]	20.652
--	--------



< 50.

Uniformity of pixels across each acquisition at given integration time





# Spectrometer DC Offset Calibration Validation

2.5 ms int. time		Before cal.		After cal.				
Reports			Maximal integration time					
	Average DCOffset [DN16]	Min	236.019		Average DCOffset [DN16]	Min	-11.227	
		Mean	597.893			Mean	1.603	
		Max	678.794			Max	13.624	
	Spatial Noise [DN16]		169.838		Spatial Noise [DN16]		9.598	
Average Spectrum Histogram								

SPEC: Maximal offset level noise ( $3\sigma$ ) < 50

No OACAP for current version

Potential Problems	Possible Causes	Solutions
<ul style="list-style-type: none"><li>Pixel noise too high</li><li>Frame-to-frame noise too high</li></ul>	<ol style="list-style-type: none"><li>Increased temperature</li><li>Presence of stray light</li><li>Spectrometer HW issue</li></ol>	<ol style="list-style-type: none"><li>Check CL module spectrometer temperature, ensure temp as close to 35°C.</li><li>Ensure spectrometer shielded properly from stray light during calibration.</li><li>Check noise histogram to see if an increase in hot-pixels due to aging might have occurred. In such a case, the spectrometer might be defective.</li></ol>

The image features the ASML logo in a bold, dark blue sans-serif font on the left side. The background is a light blue gradient with abstract, flowing white lines that create a sense of motion and depth. On the right side, the text 'Q & A' is displayed in a red sans-serif font.

**ASML**

**Q & A**